

SUBSOILER

Product Details

Subsoiler

Subsoiler is a mounted type machine which cultivates the soil without leaving any raw soil between the tines due to the stand structure and by breaking the lower plow layer without carrying the infertile soil in the lower layer up to the top. Cultivation with a high operation depth may be performed with the subsoiler. It provides soil aeration, water retraction to the bottom by preventing rain water to stay on the surface and protection of the soil humidity and convenient going down for the plant roots by breaking the hard layer. Yield is increased by this operation. Purpose of Use: Cultivates even the deepest part of the soil. Gets rid of the rough soil on the land. Protects the soil against erosion from the rain or snow and stores the water in the deeper parts of the soil. Furrows can be made with adding a piece on the plough. With breaking up the soil, plant roots can develop better. Breaking up the deep part of the soil allows it to breath.

Tecnical Features	Units	Models		
		ASS1	ASS2	ASS3
Number of legs	pcs	1	2	3
Length	cm	98	130	170
Width	cm	95	100	180
Height	cm	140	140	140
Working depth	cm	50-75	50-75	50-75
Weight	kg	205	330	500
Tractor Power	hp	70-80	90-100	110-120

